



**NEW**

# DC Power Case allows easy operation of LGR's Ultraportable Analyzers

## DC Power Case

ABB offers an easy way to power any of portable analyzers, for field applications. The DC Power Case uses LiFePO<sub>4</sub> batteries and can provide up to 8 hours of continuous analyzer operation. The waterproof and lightweight DC Power case is easy to carry in the field compared to conventional automobile or deep cycle marine batteries.

### Models:

ACC-DCCASE (Ultraportable)

ACC-DCQC (QC Portable)

ACC-DCMICRO (Microportable)

**DC Power Case** (battery not included due to shipping regulations). Holds battery size of 8.2" x 7.7" x 5.1" (or smaller) and includes all battery terminal connections with ring lugs for 1/4-20 or 6mm screws, 2x automotive DC socket outputs – cigarette lighter style. User must supply a suitable battery (e.g., LiFePO<sub>4</sub> battery up to 40 Ah).

### Specifications

#### Case Size:

13.4" x 11.6" x 6"

#### Weight without battery:

4.1 lbs (1.9 kg)

For more information please email us at [icos.sales@ca.abb.com](mailto:icos.sales@ca.abb.com)